




DUSTER
AND
MIST BLOWER
Model NF40
PARTS MANUAL

Handwritten scribbles:
- To the right of "AND": a scribble of several overlapping circles.
- Below "MIST BLOWER": a scribble of several overlapping vertical lines.



Machine Body

NF40

Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.	Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.
1	NF04S-0150A	Muffler setting plate ass'y.	7000	1	59	NF04S-4105C	Quantity-control plate cap	4414	1
2	NF04S-1101	Volute case (front)	7001	1	60	NF04S-4106B	Pipe	4415	1
3	NF04S-1102	Volute case (rear)	7002	1	61	NF04S-4109A	Quantity-control plate packing	4416	2
4	NF04S-1103	Tank holder	4386	1	62	NF04S-4110A	Blower pipe	4417	1
5	NF04S-1104E	Bend pipe	7003	1	63	NF04S-4111A	Knob nut	4418	1
6	NF04S-1105B	Blower pipe joint (A)	4387	1	64	NF04S-4112A	Seal rubber	4419	1
7	FH04S-1106	Screw (5×67)	4388	2	65	NF40-4102A	Clumping plate packing	4420	2
8	NF04S-1108A	Grommet	4389	1	66	NF04S-4114	Addition valve	4421	1
9	NF04S-1109B	Engine cover	7005	1	66	NF04S-4115A	Addition valve	4422	1
14	NF04S-4107A	Exhaust pipe	4390	1	67	NF04S-4118/1B	Screw (6×26)	4423	4
15	NF04S-5101A	Wire clamp plate	4391	1	68	NF40-4101	Clamping plate	4424	1
16	NF04S-1114	Impeller spacer	7006	1	69	NF04S-4121A	Guard	4425	2
17	NF31-119/1	Impeller	7009	1	70	NF04S-5102C	Arm plate	4426	1
18	NF04S-1115	Blower duster cover	7007	1	71	NF04S-9106	Label	4427	1
19	NF11-311	Distributing pipe fixture	4392	2	72	NF04S-4129	Cap	4428	1
25	FH04-S0077	Shoulder band set	4393	1	73	NF12-627	Ball	4429	1
25	NF40-0052	Shoulder band set	4394	1	74	NF12-628B	Spring (for addition lever)	4430	1
26	NF04S-0201F	Frame complete	4395	1	75	RS02B-4113	Packing (plug)	4431	1
27	NF40-0201	Shoulder pad complete	7012	1	76	0200 08989 1	Washer M8	4432	1
28	NF40-2101A	Vibration-proof rubber	4396	4	77	NF04S-4122	Plate	4433	1
35	NF40-0301	Fuel tank cap complete (incl. 36, 37)	4397	1	78	NF40-6101A	Joint snap ring	4434	1
36	NF11-129/2	Fuel tank cap partition plate	4398	1	79	NF04S-4116A	Compression pipe joint	4435	1
37	0641 20999 0	Fuel filter	4399	1	80	FH04-S0090A	Lever complete (incl. 81-89, 122, 140)	4436	1
38	NF04-301A	Fuel tank	4400	1	81	FH04-5018B	Lever bracket complete	4437	1
39	NF04S-0350	Nipple assembly	4401	1	82	FH04-5019A	Quantity-control lever complete	4438	1
40	KN22-321	Fuel cock packing	4402	1	83	FH04-5116	Gauge plate	4439	1
41	0186 09999 1	Nut M10 OF21-119	4403	1	84	FH04-5117	Throttle lever (A)	4440	1
42	0641 27999 0	Fuel filter NF32-118	4404	1	85	FH04-5118	Throttle lever (B)	4441	1
43	NF04S-3101/1	Fuel pipe	7015	1	86	FH04-5119	Spring	4442	1
50	NF40-0402	Mist tank cap complete (incl. 51-53)	4405	1	87	FH04-5120	Knob	4443	2
51	NF30-4101	Element support plate	4406	1	88	NF04S-9104	Label	4444	1
52	NF32-259	Element	4407	2	89	FH04-5123	Rock washer	4445	1
53	NF40-9120	Label	4408	1	90	0140 05995 0	Wing bolt NF04S-5103	4446	2
55	NF04S-0450A	Addition lever assembly	4409	1	92	FH03-S0020	Stop button complete (incl. 93)	4447	1
56	NF04S-4101D	Mist tank	4410	1	93	FH04-5114	Dust cap	4448	1
57	NF04S-4120C	Big type mist tank	4411	1	94	NF04S-0501/1	Quantity-control wire comp.	4449	1
58	NF04S-4103/3A	Quantity-control plate	4412	1	95	NF40-4104	Quantity-control plate packing (lower)	4450	1
58	NF04S-4104/1B	Quantity-control plate supporter	4413	1	96	FH04-5020A	Throttle wire complete	4451	1


Machine Body

NF40

Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.	Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.
97	NF40-4103A	Quantity-control spacer	4452	1					
98	NF40-4107	Cap nut	4453	4					
100	NF04S-6101D	Mist plug	4454	1					
101	NF04S-6103C	Suction pipe	4455	1					
102	NF04S-6110D	Compression pipe	4456	1					
103	NF04S-6105C	Packing (mist plug)	4457	1					
104	NF40-6102A	Plug (mist)	4458	1					
105	NF40-6103	Cap packing (mist)	4459	1					
110	FH04S-8109	Hose clamp	4460	1					
111	FH03-8106A	Hose clamp	4461	1					
112	NF04S-9121	Corrugated pipe	7059	1					
120	00113 0618 0	Bolt M6×18	7018	4					
121	0103 06998 0	Bolt M6×14 FH03-4106	4462	4					
122	0170 06999 0	Nut M6 FH04-2101	4463	7					
123	00218 1000 0	Nut M10	4464	1					
124	00227 0400 0	Nut M4	1426	1					
125	0170 04999 0	Nut M4 NF04S-4124	4465	1					
126	0170 05998 0	Nut M5 FH03-1108	4466	9					
127	00626 3085 0	O-ring	7025	1					
128	0200 05998 0	Washer M5 FH03-5107	4467	7					
129	0200 06993 0	Washer M6 FH04S-1118	4468	10					
130	00311 1000 0	Washer M10	7065	2					
131	00312 0400 0	Washer M4	1113	1					
132	0200 05997 0	Washer M5 FH04S-2103	4469	4					
133	0203 05999 0	Spring washer M5 FH03-1109	4470	10					
134	0203 06998 0	Spring washer M6 FH03-4108	4471	12					
135	00320 1000 0	Spring washer M10	7023	1					
136	00320 0400 0	Spring washer M4	1293	1					
137	0203 04999 0	Spring washer M4	4472	1					
138	00431 0305 0	Screw (pan head) M3	4473	1					
139	0140 04995 0	Screw M4×16 NF04S-4128	4474	2					
140	0140 05998 0	Screw M5×10 FH04-3103	4475	7					
141	0140 05994 0	Screw M5×18 FH04S-1120	4476	5					
142	0140 05997 0	Screw M5×20 FH04-1107	4477	2					
143	0140 06996 0	Screw M6×16 NF04S-3102	4478	3					
144	0140 06998 0	Screw M6×20 FH03-1110	4479	4					
145	0140 05995 0	Screw M5×12	4480	5					
146	00371 0600 0	Gasket (fiber) M6	4481	8					




MEMO



Engine Body

NF40



Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.	Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.
1	EC04-072	Crank case complete (incl. 2-7)	1210	1	81	0650 14995 0	Spark plug		1
2	0440 12999 1	Oil seal (front)	1002	1	83	0170 08996 0	Nut (left)	1278	1
3	0440 15997 1	Oil seal (rear)	1212	1	84	0203 08999 0	Spring washer (left)	1440	1
4	0600 15988 0	Ball bearing	1213	2	104	00218 0600 0	Nut	1290	6
5	EC03-071	Crank case packing set	1214	1	106	00310 0800 0	Washer	1428	1
6	0119 05994 0	Bolt (socket head)	1215	4	108	00320 0600 0	Spring washer	1294	6
7	0105 06994 0	Stud	1216	6	112	00431 0416 0	Screw (pan head)	1298	2
8	EC04-031i	Cylinder ass'y. (incl. 7)	7026	1	114	00532 0310 0	Woodruff key	1077	1
9	EC03-109A	Cylinder packing	1218	1	135	0566 05998 0	Clamp	7043	1
10	EC04-091A	Lead complete	7027	1	136	00310 0500 0	Washer M5	1183	1
11	EC04-104C	Carburetor bracket	7028	1	137	00431 0510 0	Screw (pan head) M5x10	1287	1
12	EC03-115	Lead bracket packing	4014	2	138	00532 0320 0	Woodruff key	7044	1
14	0119 05995 0	Bolt (socket head)	1223	4	139	EC02-908b	Label	4517	1
21	EC04-0204A	Crank shaft complete	7029	1					
22	EC04-2301	Piston	7030	1					
23	EC04-207A	Piston pin	1228	1					
24	EC04-210A	Piston ring	1229	2					
25	0565 11999 0	Clip	1230	2					
26	0610 12996 1	Needle bearing	1231	1					
32	EC04-0505 HA	Recoil starter complete (incl. 33-42)	4504	1					
33	A54102500100	Reel plate	4505	1					
34	A60002200000	Spiral spring	4506	1					
35	A55002500001	Ratchet	4507	1					
36	A30302500010	Friction complete	4508	1					
37	A60102100000	Friction spring	4509	1					
38	A60502500000	Return spring	4510	1					
39	A60702500010	Set screw	4511	1					
40	A57110900000	Starter rope	4512	1					
41	A50403100101	Starter knod	4513	1					
42	276057521001	Hexagonal cap nut	4514	1					
45	EC04-0364	Muffler assembly	7038	1					
47	EC04-3122	Muffler gasket	1341	1					
48	0119 05995 0	Bolt (socket head)	1223	3					
50	NF40-9101	Label	4515	1					
73	EC04-0718A	C.D.I magneto complete	7040	1					
74	11100100100	Flywheel	7041	1					
75	11400172000	Ignition coil	4516	1					
80	KM61-088c	Plug cap complete	1275	1					



Carburetor

NF40

Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.	Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.
1	EC04-0682	Carburetor complete (incl. 2-31)	7045	1					
2	CK/31	Cock body assembly	4043	1					
3	H2-832-16001	Piston valve #1.0	4518	1					
4	J8-3N05	Jet needle	7047	1					
5	MD14/40	E-ring	1305	1					
6	VM14c1/38b	Spring seat	1306	1					
7	VM15/24A	Spring	1307	1					
8	VM16/200	Top	4046	1					
9	VM12/43	Cap	4047	1					
10	MD13/44	Cable guide	4048	1					
11	M21/15	Cable adjuster lock nut	4049	1					
12	VM24/148	Cable adjuster	1312	1					
13	N102-221	Main jet #77.5	4050	1					
14	VM15/173	Needle assembly	4051	1					
15	VM15/353	Float arm	4052	1					
16	VM15/264	Float pin	1317	1					
17	VM15/351	Gasket	4053	1					
18	VM13/139	Float	4054	1					
19	VM13/188	Float chamber body	7048	1					
20	EC03-S0010	Guide screw assembly	4056	1					
21	VM13/68A	O-ring	1323	1					
22	VM13/211	Clip	4057	1					
23	B2=0630	Bolt	1325	1					
24	B34/83	Washer	1326	1					
25	VM13/215	Nut	7049	1					
26	VM15/331	Spring	7050	1					
27	VM18/164A	Throttle stop screw	7051	1					
28	CW2=0416	Spring washer cross screw	4060	2					
29	VM15/348	Gasket	4061	1					
30	VM13/210	Filter	4062	1					
31	CW2=0414	Spring washer cross screw	1333	1					
32	EC04-0335B	Air cleaner assembly (incl. 33, 35, 36)	7052	2					
33	0736 36998 0	Label	7053	1					
34	00436 0410 0	Screw assembly M4x10	4065	4					
35	EC04-3304A	Air cleaner cap	4518	1					
36	EC04-3305	Element	7054	2					



Carswell Import & Marketing Associates, Inc./Carswell Distributing Company
3750 N. Liberty Street • Post Office Box 4193 • Winston-Salem, North Carolina 27115