




**GRASS TRIMMER/
BRUSH CUTTER**

MODEL NB211C

PARTS MANUAL



Machine body

2

NB211C

Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.	Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.
1	621 10010 00	Pipe case ass'y (incl. 2)	6000	1	41	0140 05981 0	Screw pan head	6905	2
2	621 10030 00	Bearing compl.	6001	5	42	541 50011 60	Nut	6906	2
3	621 15003 00	Long shaft	6002	1	43	0043 10514 0	Screw pan head	8152	1
4	621 10050 00	Damper pin	6003	1	44	616 55002 00	Wire	6907	1
5	621 95013 00	Label	6004	1	45	00919 1209 0	Clip tube	6908	1
6	621 30030 00	Gear box ass'y (incl. 7-14, 34-36)	6005	1					
7	621 30050 00	Gear box compl.	6006	1					
8	621 30040 00	Gear set	6007	1					
9	621 25003 00	Ball bearing (#TC16267)	6008	1					
10	621 35005 00	Oil seal (TC16267)	6009	1					
11	641 35006 00	Bolt	6110	1					
12	621 85000 001	Washer (upper)	6111	1					
13	621 80030 00	Washer compl.	6112	1					
14	625 85005 01	Nut (M8 L)	6113	1					
15	621 95004 00	Washer (M14)	6114	1					
16	620 70040 00	Hanger compl.	6115	1					
17	625 80150 00	Safety cover ass'y (incl. 18, 19, 26)	6116	1					
18	625 80140 00	Safety cover	6117	1					
19	625 85037 00	Safety cover fixture	6118	1					
20	621 85002 00	Safety guard	6119	1					
21	621 45000 00	Handle	6120	1					
22	621 45004 00	Grip	6721	1					
24	615 55001.00	Throttle wire compl.	6901	1					
25	621 50090 00	Control lever (incl. 42, 43)	6902	1					
26	0119 05985 0	Bolt (socket head) (M5x14SW)	6125	3					
27	0119 05986 0	Bolt (socket head) (M5x33)	6126	3					
28	0119 05989 0	Bolt (socket head) (M5x25SW)	6127	1					
29	0119 05990 0	Bolt (socket head) (M5x12SW)	6128	3					
30	0203 08999 0	Spring washer (M8L)	1440	1					
31	0600 10998 0	Ball bearing (N603-214) (#6000)	1386	1					
32	00227 0500 0	Nut (M5)	1703	2					
33	0119 05978 0	Socket head bolt (M5x12SW W)	6128	2					
34	00314 2400 0	Snap ring (inner)	1187	1					
35	00314 2600 0	Snap ring (inner)	6129	1					
36	00315 0800 0	Snap ring (outer)	6130	1					
36	00322 1400 0	Wave washer (M14)	6131	1					
36	621 55006 00	Stand	3526	1					
39	0119 05995 0	Bolt (socket head) M5x18SW	1223	1					
40	00320 0500 0	Spring washer (M5)	1286	1					

692

Have set

1 6120

3-6126

3-1703


1-6116

1-6003

1-6131

1 6114


1 3505



Engine body

NB211C

Ref. No.	Mfg. 's No.	Part Name	Our Part No.	Qty.	Ref. No.	Mfg. 's No.	Part Name	Our Part No.	Qty.
1	5211003000	Crankcase compl. (incl. 2-4)	6132	1	40	5217001000	Magneto ass'y (incl. 41, 42)	6164	1
2	0440 12999 1	Oil seal	1002	2	41	5217001010	Flywheel	6165	1
3	0600 12992 0	Ball bearing	1003	2	42	5217001020	Ignition coil	6166	1
4	5211500400	Crankcase packing	6133	1	43	5217500000	Plug cap	6167	1
5	5211500200B	Cylinder	6134	1	44	0241055000	Grommet	6168	1
6	5215500100	Main cover	6135	1	45	0654 00995 2	Plug cap spring	6169	1
7	0650 14981 0	Spark plug (NGK-BM7A)	BM7A	1	46	0662009840	Stop button compl.	6170	1
8	5211500300	Cylinder packing	6136	1	47	5213004000	(WZ) Insulator ass'y (incl. 48)	6171	1
9	5212001002	Crankshaft compl.	6137	1	48	00217 0400 0	Nut (insulator)	1112	2
10	5212500200	Piston	6138	1	49	5203500200	Insulator packing	6172	1
11	5212500400	Piston pin	6139	1	50	5213501600	(WZ) Gasket 31687	6173	1
12	5212500500	Piston ring	6140	2	51	6215500400	Holder case	6174	1
13	0565 07999 0	Clip	1015	2	52	5215500300	Plate	6175	1
14	5215001000	Recoil starter compl. (incl. 15-26, 75, 76)	6141	1	53	6212500300	Ball bearing	6176	1
15	5215002000	Recoil starter ass'y (incl. 16-21, 75, 76)	6142	1	54	0031424000	Snap ring (inner)	1187	1
16	5215002110	Starter knob	7037	1	55	6212001000	Clutch drum	6177	1
17	5215002030	Spiral spring	6143	1	56	0031508000	Snap ring (outer)	6178	1
18	5215002060	Starter rope	1021	1	57	6212003000	Clutch compl. (incl. 58-62)	6179	1
19	5215002020	Reel	6144	1	58	6252500800	Clutch shoe	6180	2
20	5025001030	Rope guide	6145	1	59	6252500400	Clutch bolt	6181	2
21	5215002010	Starter case	6146	1	60	6252500600	Spring	6182	1
22	5215003000	Starter pulley compl. (incl. 23-26)	6147	1	61	0200089910	Wave washer	6183	2
23	5215003010	Starter pulley	6148	1	62	6202500600	Washer (B)	6184	2
24	5215003020	Ratchet	6149	1	63	00532 0310 1	Woodruff key (rear crankshaft)	1077	1
25	5215003030	Return spring	6150	1	64	5016500300	Filter	6185	1
26	5215003040	E ring	6151	1	65	0150049970	Tapping screw	6186	2
27	5215500400	Recoil starter plate	6152	1	66	0150059990	Tapping screw	6187	4
28	5215500000	Protect cover	6153	1	67	0140059690	Plus & minus screw ass'y SW-W	6188	2
29	5213003000	Muffler ass'y	6154	1	68	0200089870	Washer	6189	2
30	5213500200	Muffler gasket	6155	1	69	00113 0616 0	Bolt ass'y	6190	2
31	5213500300	Muffler clamping bolt	6156	2	70	00312 0600 0	Washer	1395	2
32	5216500400	Fuel tank	6157	1	71	00431 0516 0	Screw	6191	2
33	5236012000	Fuel tank cap compl.	6158	1	72	00435 0525 0	Screw ass'y	6192	3
34	5216500300	Tank stay	6159	1	73	00436 0518 0	Screw ass'y	4226	9
35	5216500200	Rubber cushion	6160	2	74	0119 05995 0	Bolt (socket head)	6193	2
36	5036500200	Rubber plate (1)	6161	1	75	5105015110	Set screw	6194	1
37	5036500300	Rubber plate (2)	6162	1	76	5215002040	Washer	6195	1
38	0851179990	Rubber tube compl.	6163	1	77	6219503100	Label (Model)	6196	1
39	0561059990	Hose clamp	1632	1	78	5219500200	Trade mark	6197	1
					79	5103503400	Spacer (carburetor)	3123	1




Carburetor

NB211C

NB211C

NB211C

Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.	Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.
1	5216003000	Carburetor compl. (incl. 2-41)	3501	1	40	5316005340	Screw	3175	4
2	5236006020	Spring, metering lever	3502	1	41	5316005320	Screw, metering cover	3173	2
3	5316005550	Lever, metering	3193	1	42	0140049840	Plus & minus screw ass'y W	3201	2
4	5316005150	Valve, inlet needle	3503	1					
5	5316005510	Pin, metering lever	3189	1					
6	5316005230	Gasket, metering diaphragm	6204	1					
7	5316005250	Diaphragm ass'y, metering	3171	1					
8	5316005030	Cover, metering diaphragm	3206	1					
9	5316005630	Bracket, cable	3198	1					
10	5316005450	Nut, cable adjust	6215	1					
11	5316005330	Screw, cable adjust	3120	1					
12	5316005220	Gasket, pump	3167	1					
13	5316005240	Diaphragm, pump	3170	1					
14	5316005520	Plate, pump	3192	1					
15	5316005210	Gasket, plate	3169	1					
16	5316005020	Cover ass'y, pump	3160	1					
17	5316005620	Primer, pump	3197	1					
18	5016002060	Bracket, primer pump	3194	1					
19	5316005350	Spring, high speed needle	3179	1					
20	5236006030	Needle, high speed	3181	1					
21	5316005430	Sleeve, mounting	8107	2					
22	5316005710	Filter, wick	8108	1					
23	5316005660	Gasket, intake cap	8109	1					
24	5316005650	Plate, wick	8110	1					
25	5316005640	Cap, intake	8111	1					
26	5316005540	Plate, mounting sleeve	8112	2					
27	5016002050	Plate, cleaner	3119	1					
28	5316005050	Spring, filter	8113	1					
29	5016002040	Filter, air	3117	1					
30	5016002010	Cover, air cleaner	3116	1					
31	5236006010	Valve ass'y, throttle	3504	1					
32	5316005120	Ring, spring retaining	6211	1					
33	5316005460	Washer	6212	1					
34	5316005110	Swivel	8117	1					
35	5016002110	Bracket, idle screw	8118	1					
36	5316005360	Spring, idle adjust	8119	1					
37	5316005260	Screw, idle adjust	6217	1					
38	5316005140	Ring, packing	8120	1					
39	5316005310	Screw, pump cover	3172	5					



Accessories

NB211C

Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.	Ref. No.	Mfg.'s No.	Part Name	Our Part No.	Qty.
1	NB23-7002	Hanging band (incl. 2)	7113	1					
2	NB31-7102	Hook	6228	1					
3	NB21-9001	Tool kit (incl. 4)	6229	1					
4	0717 04999 0	Wrench (socket head)	7064	1					
5	NB25-8001B	Blade cover unit (9 inch)	6230	1					
6	NB02A-801B	Star blade (230×4)	NB02-9st	1					
7	NB21-9135	Instruction manual	3505	1					