




















**Parts In Stock
To Fit All Robin Trimmer Heads !**

Robin Trimmer Head Application Guide & Parts List















Trimmer Heads

LO-PROFILE TWIST FEED HEADS












	Head #	Shaft Size	Applications	Parts List
		Arbor Bolt		
	1832	8mm x 1.25 Left Hand Female Counter Bore	NB16, NB16T, NB02, NB02T, NB03, NB211, NB26-AU, NB231, NB251, NB252, NB27, NB31, NB281, NB321, NB223, NB253, NB2001, BH2500, NB020A, NB2050, NB2250Z, NB2950.	 1938 - Housing  1939 L.H. - Spool  1939 R.H. - Spool  SS-105 - Spring  1937 L.H. - Knob  1937 R.H. - Knob  1934 - Eyelets
		UB-1005		
	1833	8mm x 1.25 Right Hand Female Counter Bore	NB23, NB171, NBF251, NBF252.	 1938 - Housing  1939 L.H. - Spool  1939 R.H. - Spool  SS-105 - Spring  1937 L.H. - Knob  1937 R.H. - Knob  1934 - Eyelets
		UB-1007		

MANUAL HEAVY-DUTY TWIST FEED HEADS










	Head #	Shaft Size	Applications	Parts List
		Arbor Bolt		
	1834	10mm x 1.00 Left Hand Female Counter Bore	NB04, NB30, NB50, NB351, NB411.	 1933 - Housing  1935 - Spool  SS-105 - Spring  1937 L.H. - Knob  1934 - Eyelets
		UB-1013		
	1874	10mm x 1.25 Left Hand Female Counter Bore	BH3500AU, BH3600AU.	 1933 - Housing  1935 - Spool  SS-105 - Spring  1937 L.H. - Knob  1934 - Eyelets
		UB-1014		

Trimmer Heads

SEMI-MATIC BUMP & FEED HEADS








	Head #	Shaft Size	Applications	Parts List
		Arbor Bolt		
	1835	8mm x 1.25 Left Hand Female Counter Bore	NB16, NB16T, NB02, NB02T, NB03, NB211, NB26-AU, NB231, NB251, NB252, NB27, NB31, NB281, NB321, NB223, NB253, NB2001, BH2500, NB020A, NB2050, NB2250Z, NB2950.	 1910SM - Housing  SN-307L - Spool L.H.  SN-307R - Spool R.H. <i>A see PAGE → (5)</i>
		UB-1005		
	1836	8mm x 1.25 Right Hand Female Counter Bore	NB23, NB171, NBF251, NBF252.	 SN-305L - Outer L  SN-306L - Inner Cam L.H.  SN-306R - Inner Cam R.H.
		UB-1007		
	1873	10mm x 1.25 Left Hand Female Counter Bore	BH3500AU, BH3600AU.	 SS-303 - Spring  1912SM - Washer
		UB-1014		

COMMERCIAL BUMP & FEED HEADS








	Head #	Shaft Size	Applications	Parts List
		Arbor Bolt		
	1839	8mm x 1.25 Left Hand Female Counter Bore	NB16, NB16T, NB02, NB02T, NB03, NB211, NB26-AU, NB231, NB251, NB252, NB27, NB31, NB281, NB321, NB223, NB253, NB2001, BH2500, NB020A, NB2050, NB2250Z, NB2950.	 SN-322 - Housing  SN-323 L.H. - Spool  SN-324 - Button
		UB-1005		
	1838	10mm x 1.00 Left Hand Female Counter Bore	NB04, NB30, NB50, NB351, NB411.	 SN-325 - Cover  SS-303 - Spring  SN-356 L.H. - Nut  1934 - Eyelets
		UB-1013		


Trimmer Heads

MINI (2-LINE) BUMP & FEED HEADS


Head #	Shaft Size		Applications	Parts List
	Arbor Bolt			
1802	8mm x 1.25 Left Hand Female Counter Bore		NB16, NB16T, NB02, NB02T, NB03, NB211, NB26-AU, NB231, NB251, NB252, NB27, NB31, NB281, NB321, NB223, NB253, NB2001, BH2500, NB020A, NB2050, NB2250Z, NB2950.	 { SN-341 - Housing L.H. (Red) SN-341BL - Housing L.H. (Black) SN-341RR - Housing R.H. (Red) SN-341BR - Housing R.H. (Black) SN-349 - Spool L.H. (Red) SN-349RH - Spool R.H. (Black) SN-349B - Spool L.H. (Black) }   SN-347 - Button
	UB-1005			
1803	8mm x 1.25 Right Hand Female Counter Bore		NB23, NB171, NBF251, NBF252.	SN-348 - Cover L.H. (Red) SN-348R - Cover R.H. (Red) SN-348BR - Cover R.H. (Black) SN-348B - Cover L.H. (Red) }   SS-354 - Spring SN-356 L.H. - Nut }  SN-356 R.H. - Nut }  1934 - Eyelets
	UB-1007			

MINI (1-LINE) BUMP & FEED HEADS


Head #	Shaft Size		Applications	Parts List
	Arbor Bolt			
1861	8mm x 1.25 Left Hand Female Counter Bore		NB16, NB16T, NB02, NB02T, NB03, NB211, NB26-AU, NB231, NB251, NB252, NB27, NB31, NB281, NB321, NB223, NB253, NB2001, BH2500, NB020A, NB2050, NB2250Z, NB2950.	 { SN-352 - Housing L.H. (Black) SN-352LH - Housing R.H. (Red) SN-355 L.H. - Spool }  SN-355 R.H. - Spool }  SN-357 - Button
	UB-1005			
1863	8mm x 1.25 Right Hand Female Counter Bore		NB23, NB171, NBF251, NBF252.	SN-358 - Cover }   SS-354 - Spring SN-356 L.H. - Nut }  SN-356 R.H. - Nut }  1934 - Eyelets
	UB-1007			



2 SLOT



4 SLOT



6 SLOT